


NSL wall hardware



NSL structures:

Whatever the structure may be:

- ① **OBLF:** Freestanding floor mounted structure
- ② **OBLW:** Wallmounted system
- ③ **3rd Party:** Various

Take care when handling the monitor!

The edge of the screen is very narrow and shocks to the edge of the screen may result in dark lines or cracked glass.

Page 1

Opening the Barco NSL Wall:

Screens need to be opened from the top. If this rule is not respected, you risk:

- ① damaging the screen above (if the screen was secured during installation).
- ② that the screen is lifted from its' supports.
- ③ To open the screen, place the palms of your hands, over the lock positions, and push with both hands evenly to open the locks, and let the screen hinge open. (Uneven pressure may leave one lock open and one lock closed.)

Screen Cleaning:

- ④ Use soft cotton swab or cloth. Preferably dry. A mild glass cleaning agent can be used if sprayed on the cloth. Wipe till dry.

On Screen Menu:

If needed, the screen can be controlled on the screen itself, however, the control buttons and the IR receiver for the remote are in the back of the screen!

- ① NSL buttons
- ② NSL remote

BARCO

Visibly yours

